

### **ATTENTION**

Inspect all materials for damage or missing parts. If you discover damaged or missing materials, in the USA please notify the factory at (800) 233-8493, and in Canada (888) 895-8955 for customer service.

Construction Specialties (CS) products must be installed in accordance with their respective instructions! Failure to follow the instructions may void any product warranties and result in an unsuccessful installation. For specific questions regarding installation of any CS product, please call the factory in the USA at (800) 233-8493 or email [iwptechsupport@c-sgroup.com](mailto:iwptechsupport@c-sgroup.com). If in Canada, please call (888) 895-8955.

For more information on Construction Specialties products, visit our website at [www.c-sgroup.com](http://www.c-sgroup.com).

### **IMPORTANT NOTES**

1. Rubber material may appear dull grey rather than black. This is normal and is easily rectified by cleaning.
2. Always store the material flat to avoid it taking on an abnormal shape.
3. All material is supplied in stock lengths of 9'-10".
4. Material must reach 65°F minimum to 75°F maximum 24 hours prior to installation. This is essential to minimize the expansion and contraction of the material.
5. When cutting the industrial bumper sections, CS recommends using an 80-100 tooth carbide tipped saw blade or equivalent to minimize tearing and maintain joint alignment. Care must be taken when cutting, as rubber materials have a tendency to snag.
6. When field forming radius bumpers, be sure to apply needed pressure across length of guard.
7. Do not over tighten fasteners as they could strip or cross-thread which would result in bumper not being fastened to the wall properly.
8. Splice joints can simply be butt jointed.
9. Clean products of any obvious dirty marks using mild detergent and water.