

| Acrovyn® Wall Protection Systems

Acrovyn Wall Protection Systems Care and Maintenance

All Acrovyn wall covering or profile products (including Chameleon™ Collection and Acrovyn by Design®) can be cleaned by using the following instructions:

1. Light soil, crayon, pencil, lipstick, blood and other mild staining agents can usually be removed by using a soft cloth with mild soap and water. Additional household cleaners could be used, such as Green Works® All-Purpose Cleaner, Seventh Generation™ Multi-Surface Cleaner, and Mrs. Meyer's® All-Purpose Cleaner or an equivalent product. A Mr. Clean® Magic Eraser™ can be used in concert with any of these cleaners. Always scrub with the grain of the Acrovyn. The cleaned surface should always be “rinse wiped” with clean water and dried to remove any remaining residue.
2. Stubborn stains, ball point pen, permanent marker, dry erase marker, paint and shoe scuff s can usually be removed by using a Mr. Clean® Magic Eraser™ in concert with a product like Spartan Graffiti Remover SAC®.

Again, always scrub with the grain and “rinse wipe.”

- **Do not** use methyl ethyl ketone (MEK), cleaners containing MEK, bleach or any other cleaners containing harsh solvents on any Acrovyn product. Powdered cleansers are not recommended as they are abrasive and tend to leave a troubling residue if not utilized properly.
- **Do not** use Scotch-Brite®, Brillo®, S.O.S.® pads or steel wool on any Acrovyn products.

Acrovyn Renaissance™ Collection Care and Maintenance

Renaissance Wood Collection

All wood components can be cleaned by using the following instructions:

1. Chips, nicks, dents and deep scratches can be repaired by filling with a Fil-Stik™ or Patchal Pencil™. Either rub in or press in, then remove any excess. Color may be applied with an Instant Touch-up™ Marker or Pro- Mark II™ Marker.
2. Surface scratches, scuff s or rubbed edges may be re-colored with an Instant Touch-up™ Marker or Pro- Mark II™ Marker.
3. Dust and light soil can usually be removed by using a soft cloth with mild soap and water.
 - **Do not** wax the handrail.
 - **Do not** use solvent-based cleaners on any wood.

Renaissance Metal Collection

All stainless steel and aluminum components can be cleaned by using the following instructions:

1. Dust and light soil can usually be removed by using a soft cloth with mild soap and water.
 2. Stainless steel and aluminum components will easily maintain their brilliant appearance when occasionally polished with a quality metal cleaner, such as Maas® Polishing Creme.
- **Do not** use abrasive cleaners, Scotch-Brite™, Brillo®, S.O.S® pads or steel wool on any metal.