












Curtain Accessories

	ITEM	DETAILS	FINISH OPTIONS
	Carrier Gate	Used at all curtain stacking points. Assembled with machine screw. Provides easy insertion or removal of carrier.	<ul style="list-style-type: none"> • Gray • White • Aluminum • Custom
	Carrier Stop	Used at the ends of curtain tracks or bends. Made of molded nylon or aluminum.	<ul style="list-style-type: none"> • Gray • White • Aluminum • Custom
	Grid Ceiling Clip	Allow for quick & easy installation of the suspended aluminum track to horizontal tegular tile grids (T-grids).	<ul style="list-style-type: none"> • Gray • White
	Splice	6" (152.4mm) splices are used where one-piece sections are not long enough or where radius & straight tracks connect.	<ul style="list-style-type: none"> • Anodized Aluminum • White Powdercoat
	Offsets	Used to wrap track around the foot of the bed. 30° - 45° are supplied 2' x 2' (0.61m x 0.61m) after the 12" (304.8mm) radius. Can be supplied in custom lengths.	<ul style="list-style-type: none"> • Anodized Aluminum • White Powdercoat
	Wall Socket	Nylon socket designed to secure suspended mounted track systems to the wall.	<ul style="list-style-type: none"> • Gray • White
	General Carrier 1062N Narrowline Carrier NL1062	Combines a nylon axle & a wheel with a nickel-plated brass bead chain & polished aluminum hook.	
	General Carrier 1075 for 6062 Track	A super-smooth economical carrier manufactured completely from nylon, including nylon axle wheels.	
	Spool Carrier SP062 for 6062 Track	Manufactured from Nylon/Delrin®, these carriers provide fast, free movement.	
	Breakaway Carrier SB062 for 6062 Track	For use in behavioral health spaces. The hook is designed to pop out of the axle when 8 to 10 lbs. of pressure is applied. This carrier can be reassembled without removing it from the track.	
	Breakaway Carrier SBC30 for 6062 Track	For use in behavioral health spaces. This new patented carrier is designed to pop out on one side when 8.5 to 10.5 lbs. of pressure is applied. The entire carrier remains in the track while releasing the curtain. The beaded portion of the carrier can be reinserted for reuse.	<ul style="list-style-type: none"> • Nylon



Learn More →

Curtain Accessories

	ITEM	DETAILS	FINISH OPTIONS
	Curtain Tieback	Two options to match the design of curtain. Lengths are fabricated to accommodate the width of curtain.	<ul style="list-style-type: none"> • Nickel-Plated Bead Chain • Fabric
	Beaded Chain Drop	Available in nickel-plated brass chain with an aluminum hook. In applications where NFPA* standards are required, this product can be used on curtains as a substitute for traditional nylon mesh.	
	Shower Curtain Rod	1" (26mm) and 1¼" (31.75mm) outer diameter stainless steel Shower Curtain Rods available with radius options available. Five ball shower hooks standard.	