


# Guide for Creating a Concrete Recess


## 1. Creating the overall shape




- Overall shape layout should match architectural contract documents or manufacturer's reviewed and approved shop drawings
- Corners should be square or match appropriate angles
- Consider and plan for notch outs, radii, columns, pedestals or protrusions

## 2. Depth

### Finished Floor Conditions





Concrete



Finished Materials

### Tolerances




 = Concrete


FF = Finished Flooring

- Achieving exact dimensions for the recess depth can be difficult using concrete
- Oversizing the depth of the pour may be necessary. We recommend pouring no deeper than 1/2" over the required depth
- Use self-leveling grout to achieve the exact dimensional requirement and to provide a smooth surface

### 3. Side walls + conditions



- Side walls should be plumb to accommodate perimeter frames
- Side wall/floor angle = 90 degrees



- Finished recess should have a consistent depth throughout

### 4. Model depth guide

Model	No Frame	Tapered Angle (TNG)	Level Base (LB)	Deep Pit (NPIDP)
Pedimat® (M1/M2)	1/2"	1/2"	3/4"	X
Helix® (HZ1/HZ2)	1/2"	1/2"	3/4"	X
Pedigrid® (G1/G8)	1 11/16"	X	1 11/16"	4 3/16"
PediTred® LP (G3)	1/2"	1/2"	3/4"	X
PediTred® (G4/G7)	3/4"	3/4"	1	X
GridLine® (G6) - 3/8"	3/8"	X	1/2"	X
GridLine® (G6)   GridLine® 2 (G6P) - 5/8"	5/8"	X	3/4"	X
GridLine® (G6)   GridLine® 2 (G6P) - 1 1/8"	1 1/8"	X	1 1/4"	Varies; < 8"
Floormations®	1/2" OR 3/4"	X	X	X

**Need Help? Call 800.233.8493**