




MODELS SF-200/500 AND SC-400 INSTALLATION INSTRUCTIONS



MODEL SC PRIMARY SEAL



MODEL SF-200 PRIMARY SEAL



IMPORTANT INFORMATION

Prior to the commencement of Installation, all materials **MUST** be inspected for Damage. Any damage must be reported to CONSTRUCTION SPECIALTIES, INC., as soon as possible, so that replacement materials may be furnished without delay.

All work must be completed as per Architect's Approved "Shop Drawings", and in accordance with these Installation Instructions. When installation is complete, all materials must be protected from damage until the Architect's FINAL INSPECTION.

All materials should be arranged in the order that they are to be installed. All hardware required for each portion of the work should be placed with the appropriate materials.

Please review all Approved Shop Drawings and this Document to familiarize yourself with all the details and components of this assembly.

IMPORTANT:

READ THROUGH ALL INSTRUCTIONS PRIOR TO STARTING INSTALLATION

3/12/25



Construction Specialties™

6696 Route 405 Highway, Muncy PA 17756
(800) 233-8493 • Fax (570) 546-5169 • www.c-sgroup.com

This document is the property of Construction Specialties, Inc. and contains CONFIDENTIAL PROPRIETARY INFORMATION that is not to be disclosed to third parties and is not to be used without approval in writing from Construction Specialties, Inc.

STEP 1


INSTALLATION OF ALUMINUM FRAMES

Notes:

Before beginning installation, review the architectural drawings and approved Construction Specialties Inc. shop drawings to familiarize yourself with the joint cover models and locations.

Check all of the joint cover components to confirm that the correct joint cover model and size have been received. Also, check for materials that may have been damaged during shipping. Report all incorrect and/or damaged components to CS at 800-233-8493.

*Read through all the steps of these instructions prior to beginning work.



FLAT WALL INSTALLATION


Step 1:

Flat Wall Condition:

- 1.) Apply the CS supplied Butyl Tape to the back of the Aluminum Frames.
- 2.) Peel paper backing off and seat the frames at the appropriate dimension in from the joint edge. (Refer to CS shop drawings.)
- 3.) Using the Frame as a template, drill the holes for the CS supplied Fasteners and anchor the Frames into the joint. Note: Do not forget to use the CS supplied Sealing Washer with each Fastener.
- 4.) Continue with installation of the Aluminum Frames until all of the Frames, on both sides of the joint, for the entire run are installed.


Note:

Each Aluminum Frame is double punched to accept either a masonry anchor or a TEK screw with a Sealing Washer depending on the installation condition. All holes that do not receive a fastener and all frame butt joints should be caulked with the CS supplied Dymonic 100.



STEP 1 (Cont.)

INSTALLATION OF ALUMINUM FRAMES



CORNER WALL/ADHESIVE INSTALLATION

Step 1 :

Adhesive Application:

Note: At corner wall applications, at smaller joint widths, it is not possible to drill to anchor the wall side frame. Also, at substrates where a mechanical anchor cannot be used, the frame(s) may be installed using a structural adhesive (Sikaflex-552). Note: Minimum application temperature is 40°F.

- 1.) Any substrate that has a glossy surface must be abraded with 3M Scotch-Brite (or similar), Fine or Extra Fine grade. Clean the abraded surface with Isopropyl Alcohol minimum 70% on clean dry rags. For non-glossy substrates, such as concrete, assure that the substrate is clean, dry and free from all traces of grease, oil, wax and dust.
- 2.) Clean the back side of a piece of the Alum. Frame with Isopropyl Alcohol minimum 70% on clean dry rags.
- 3.) Apply a 1/4" bead of the CS supplied Sikaflex 552 to the back of the Frame at the location shown above.
- 4.) Beginning at one end of the run, start installation of the Frames by positioning the Frame at the appropriate dimension recessed back from the joint edge, consistent along the full length. (Reference CS shop drawings).
- 5.) Seat the Frame against the substrate and apply slight pressure to spread the adhesive and to assure consistent contact against the surface. Note: The front edge of the Frame should not be tight to the substrate leaving approximately 1/16" gap. Adjust positioning as needed.
- 6.) Use strips of masking tape, painters tape or duct tape, or Styrofoam wedge blocks to hold the Frame in position until the adhesive sets sufficiently (minimum 24-hours, 48- hours when substrate and frame temperatures are below 60°F.).
- 7.) Repeat for additional Frame lengths as needed.
- 8.) Proceed to Step 2 when the frames only move slightly when pushed inward on the front edges.


Note: Refer to the Sikaflex 552 product data sheet for additional manufacturer recommended application guidelines.

Note: CS has tested the Sikaflex 552 for performance on various substrates, however, before proceeding a bond trial should be conducted at an inconspicuous location.

Note: If additional adhesive is needed urgently, Liquid Nails, Fuze-It can be substituted. CS has tested the Fuze-It for performance on various substrates and found it to be acceptable for this application. Fuze-It is available through Grainger and many home improvement locations. Follow the surface preparation guidelines above, as well as, the manufacturer's guidelines.

STEP 2

SECONDARY SEAL INSTALLATION




Step 2:

1. Place a small bead of the CS supplied Dymonic 100 Sealant into the secondary seal receiver slot of each Frame.
2. Starting at the top of the run, install the Secondary Seal into the Aluminum Frames by pushing the seal tabs into the receiver slots. When required, splice joints in the secondary seal are to be overlapped by 6", top over bottom, and sealed with the Dymonic 100 Sealant.

STEP 3

PRIMARY SEAL INSTALLATION




Step 3:

1. Prior to installation of the Primary Seal, place a 1/8" to 3/16" bead of Dymonic 100 Sealant into the Primary Seal receiver slot of each Aluminum Frame. Note: Application of the Sealant will aid in the installation of the seal and will improve the water resistance of the cover.
2. Cut the Primary Seal to length as needed for the run. When necessary, multiple lengths of seal may have to be spliced together for the required length of the run. (See Step 4 for cutting and splicing instructions.)
3. Beginning at the top of the run, insert the tabs on the Primary Seal into the receiver slots of the frames. Use a mallet and wood block to seat the seal against the front of the frames.

STEP 4

SPLICE INSTRUCTIONS



PRIMARY SEAL SPLICE

Step 4:

Cutting:

- 1) Determine the length of seal required for the applicable area and measure and mark the seal.
- 2) Place the seal with the location to be cut into a Miter Box and flood the area to be cut with water to lubricate the saw blade.
- 3) Using a hacksaw and the CS supplied Serrated Saw Blade, make the cut using long strokes while applying downward force on the Hacksaw frame. The cut should be made with as few strokes as possible in order to prevent a ragged end on the seal.

Splicing:

- 1) Wipe surface of the Splice Bars and the ends of the seals to be bonded with Alcohol (or similar) to remove all dirt, moisture, and oils that might affect the bond.
- 2) When appropriate, apply the 3M Scotch Weld adhesive to half of each Splice Bar. Insert only the portion of the bar with adhesive into the splice bar slot of one of the seals. Important: Please observe the safety precautions on the adhesive container!
- 3) Apply the 3M Scotch Weld Adhesive to the entire cut surface of the seal and the remaining portion of the Splice Bar.
- 4) Align the two ends of each seal, insert the Splice Bar into the opposite seal and bring the ends of the seal together. Apply pressure against the ends of the seals until the Adhesive has set.
- 5) Once the Adhesive has cured, cut a piece of the Fab Tape that is wide enough to span across the entire width of the backside of the seal splice. Place the tape so that it is centered over the butt joint and press the tape firmly against the back of the seal to work the tape into all voids to create a watertight seal.