

General Information

Open the pack list on the crate's exterior. Locate the shop drawings and installation instruction inside the box. Review contents and make sure all parts are present. For a rectangular installation, the pack list will include the number of modules and frame pieces. For odd-shaped installations, a drawing will be supplied identifying the module layout in numbered sequence.

If you discover that material is missing or defective, contact our customer service department immediately: **800.233.8493**

Important Notes - Do Not Overlook

Prior to installation, ensure that the material is stored indoors and has acclimated to the environment's temperature for 24 hours.

Assess the site condition prior to installation ensuring the recess is:

- Free of debris and moisture
- The correct depth throughout
- Smooth and flat

High spots should be ground down. Low spots should be filled with a self-leveling grout. The side walls of the recess should also be checked for plumb and defects as this could affect the frame installation (if applicable). If these conditions have been met, you can begin the installation.

Tools Required

You will need a level, 5/16" masonry drill bit, flathead screwdriver, #2 Phillips-head screwdriver, tape measure, carpenter's pencil or marker, utility knife, shop vacuum, PPE (gloves, glasses, ear protection, etc.) and a trowel.

Installation Instructions



1 Ensure the recess is flat and smooth. Use non-shrink grout to fill any low spots. Grind down any high spots as well.



2 Allow 24 hours for the grout to dry before continuing with the installation.



3 Each grid module is labeled per the drawings to identify location. Begin placing modules in the recess per the shop drawing layout.

Installation Instructions (continued)



4 Modules will have spacer clips attached to one side. Spacer clips should face toward adjacent modules.



5 Continue placing modules in the correct locations per the shop drawings.




6 Make final adjustments for rail alignment.



7 Clean the unit with a vacuum.



8 If construction is to continue in the building, protect the unit with plywood sheathing.



9 Care & Maintenance: to clean beneath the grid, use a slotted screwdriver to remove grid. Place wood blocking under grid and remove panels.